

Surfactant-Based Chemical and Biological Agent Decontaminating Solution Development

Jerry S. Brown (PI)

Richard C. Hodge, Amanda S. Schilling NAVSEA, Dahlgren Surface Warfare Center Division 540-653-8162

Brownjs@nswc.navy.mil

maintaining the data needed, and c including suggestions for reducing	lection of information is estimated to completing and reviewing the collect this burden, to Washington Headqu uld be aware that notwithstanding ar DMB control number.	ion of information. Send comments arters Services, Directorate for Infor	regarding this burden estimate of mation Operations and Reports	or any other aspect of th , 1215 Jefferson Davis I	is collection of information, Highway, Suite 1204, Arlington		
1. REPORT DATE 19 NOV 2003		2. REPORT TYPE N/A		3. DATES COVE	RED		
4. TITLE AND SUBTITLE	5a. CONTRACT NUMBER						
	Chemical and Biolog	5b. GRANT NUMBER					
Solution Development				5c. PROGRAM ELEMENT NUMBER			
6. AUTHOR(S)				5d. PROJECT NUMBER			
					5e. TASK NUMBER		
					5f. WORK UNIT NUMBER		
	ZATION NAME(S) AND AD on Surface Warfare	8. PERFORMING ORGANIZATION REPORT NUMBER					
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)			
					11. SPONSOR/MONITOR'S REPORT NUMBER(S)		
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release, distribution unlimited							
13. SUPPLEMENTARY NOTES See also ADM001851, Proceedings of the 2003 Joint Service Scientific Conference on Chemical & Biological Defense Research, 17-20 November 2003., The original document contains color images.							
14. ABSTRACT							
15. SUBJECT TERMS							
16. SECURITY CLASSIFIC	17. LIMITATION OF	18. NUMBER	19a. NAME OF				
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	ABSTRACT UU	OF PAGES 20	RESPONSIBLE PERSON		

Report Documentation Page

Form Approved OMB No. 0704-0188



Background

- Current Decontaminating (Decon) Solutions (Navy HTH and Army DS-2) Are:
 - Toxic
 - Corrosive to Materials
 - Environmentally Unfriendly
- Joint Service Family of Decon Systems (JSFDS)
 Program Requirement for New Decon
 - Must Be As Effective As Current Decons
 - Effective Against Biological Agents
 - Compatible (Noncorrosive) with Military Materials
 - Environmentally "Green" and Nontoxic to User



Objectives

- Develop a Surfactant-Based Decon Solution That Will Meet JSFDS Requirements
- Most Challenging Requirements
 - Neutralization Time of 15 Minutes for VX, HD, and TGD
 - Pot Life of 12 Hours
 - Disinfect Vegetative and Endospore Forming Bacteria,
 Fungi, and Viruses in 15 Minutes
 - Noncorrosive to Military Materials
 - Nontoxic and Environmentally "Green"



Decon Formulation Components

Surfactants

- Use to Replace Organic/Halogenated Solvents to Solubilize Chemical Agents
- Must Be Stable Against Oxidation and Hydrolysis
- Utilize to Increase Biocidal Efficacy by Lowering Interfacial Tension Between Spores and Biocide

Peroxygen Compound


- Utilize as Environmentally Green Reactant for Both Chemical and Biological Agents
- Some Peracids Available in Neat Form (Peracetic acid) and In-Situ (Commercial Detergent Technology)

Catalyst

- Promote Oxidation of the Sulfur in V and HD
- Reported to Promote Hydrolysis at Lower pH (for G Agent Decontamination)



Basics of Microemulsion Formulation






MICROEMULSION FORMULATION



Identify surfactant(s) slightly soluble in the aqueous phase Identify surfactant(s) slightly soluble in the oil phase

 Combine oil soluble and water soluble surfactants to reduce interfacial tension between oil and water phase to produce microemulsion



Surfactant / Solubility Screen

J A B C D E F G H I



Oil/Water = 20/80; Surfactant = 3%; Oil = Dibutylsulfide; Water = water + 500-mg Na carbonate

J: control

A: C₁₆ Diphenyloxide sulfonate

B: C₁₄₋₁₇ sec-Alkyl sulfonate

C: C₆₋₁₆ Cocamidopropylamine oxide

D: C₁₀ Amine oxide

E: C₁₂ Amine oxide

F: C₁₄ Amine oxide

G: C₁₂₋₁₈ Amine oxide

H: C₁₈ Amine oxide

I: di-C₁₀ Amine oxide



S1/S2=

Decon Formulation Components - Surfactants

Surfactant Scan – Amine Oxides

J A B C D E F G
100/0 90/10 75/25 50/50 25/75 10/90 0/100



O/W = 20/80; (S1+S2) = 3%; V(T) = 5-mL; O = Dibutyl sulfide, W = water + 500-mg Na carbonate


J: control (no surfactant),

S1: C₁₀ Amine oxide

S2: di-C₁₀ Amine oxide



 Current System - Mixed Amine Oxide Surfactant Microemulsion



C₁₀ Amine oxide. Dimethyldecylamine oxide

Di-C₁₀ Amine oxide. Didecylmethylamine oxide



• Why Microemulsion?

- Increased Stability
- Increased Reactivity (Surface Area)

Lipophilic (Agent)

Hydrophilic (Oxidizer)



10 nm



Decon Formulation Components – Peroxygen Compound

Peroxgen Compounds

- Organic Peroxides (t-Butyl hydroperoxide)
 - Requires Catalyst to Meet Decon Reactivity Requirement
 - Stable Does Not Require Special Handling
 - One of Two Organic Peroxides That Meet DOT Shipping Regs for Bulk Shipment

Peracids

- Strong Oxidizers
- Broad Spectrum Disinfectants
- Use Neat or Generate In-Situ (Tide With Bleach)
- Stability (Handling / Storage) Can Be an Issue




Decon Formulation Components – Catalyst

- Dimanganese-Based Complex
 - Developed for Laundry and Detergent Industry
 - Catalyst Activates Stain (Mn⁴⁺ + e⁻ → Mn⁺³)
 - Stain More Susceptible to Bleach (Oxidation)
- Macrocylic Tetradentate Liqand (TAML)
 - Developed by Carnegie Mellon
 - Complexes the Peroxygen
 - Stable in Presence of Strong Oxidants
 - Defluoro Reported to Promote Hydrolysis and Oxidation at Lower pH



Decon Formulation Components – Catalyst

- Dimanganese-Based Complex
 - -1,4,7-Trimethyl-1,4,7-trizacyclononane ligands (Me3TACN)






Decon Formulation Components – Catalyst

Macrocylic Tetradentate Ligand

	<u>X</u> 1	<u>X</u> 2	<u>R</u> ₁
FeMB	Me	Н	Me
FeB	Н	Н	Me
FeF ₂ B	Н	Н	F
FeF ₂ DCB	CI	CI	F






Decon Formulation Components – Peroxygen Compound and Catalyst

Oxidation of Calmagite Dye by t-Bu Hydroperoxide

TAML FeMB and Dimanganese Catalysts






Decon Formulation Components – Peroxygen Compounds and Catalysts


Oxidation of Calmagite Dye by Peracetic Acid

TAML FeMB Catalyst



Decon Formulation Components – Peroxygen Compounds and Catalysts

Agent Decontamination by t-Bu Hydroperoxide in Microemulsion
TAML FeMB Catalyst






Decon Formulation Components – Peroxygen Compounds and Catalysts

Agent Decontamination by Peracetic Acid

Uncatalyzed





Biological Decontamination

 Peracetic Acid (PAA) Found to Be an Effective Disinfectant

Reduction in Bacillus globigii after 15 minute Exposure to Candidate Solutions

	BG Initial CFU/mL	Log Reduction, CFU/mL
Damox 1010 (1)	10^6	0 (30 min exposure)
Barlox 10S (2)	10^6	0 (30 min exposure)
PAA, 5%	10^8	4
PAA in uEm	10^8	8

⁽¹⁾ C₁₀ Amine oxide

(2) di-C₁₀ Amine oxide



Summary

- Microemulsions Developed From Oxidation and Hydrolysis Resistance Surfactants
- Peracids (Peracetic) Demonstrated Efficacy Against Chemical Agents (HD, VX, GD)
 - Efficacy Achieved Without Catalyst
- Peracids (Peacetic) Demonstrated Efficacy Against Biological Agent Simulant (BG)